

Instruction Manual

Big Bag lifter



AR-N1000



AR-N1001

Note: The Owner/Operator must read carefully and understand all the information presented here before operation.

THANK YOU FOR USING THIS BAG LIFTER. FOR YOUR SAFETY AND CORRECT OPERATION, PLEASE CAREFULLY READ THIS INSTRUCTION BEFORE USING IT.

NOTE: All of the information reported herein is based on data available at the moment of printing. The factory reserves the right to modify its own products at any moment without notice and incurring in any sanction. So it is suggested to always verify possible updates.

SAFE HANDLING

- Big Bag lifter should always be stored indoors never leave them exposed to the elements
- Once a week the lifter should be inspected by the person in charge of storage, according to the specified inspection standards.
- In bag lifter where damage is found, such as cracks or wear on the welded section, immediately stop using them regardless of the apparent size of extent of the damage
 - a . Operating condition
 - b. Condition of the opening
- Lifter which you have stopped using for safety reasons should be clearly marked as defective and stored separately

WARNING


- Make sure of the condition of the load to be lifted
- Use lifter with adequate specifications (both lifting capacity and

gravity center)

- Observe proper operating procedures


Parts Lis:

AR-N1000:



number	name	quantity
1	telescopic boom	1
2	pin shaft	1
3	chain	1
4	hanger	1
5	nut and bolt	2
6	Splint	1

AR-N1001:



number	name	quantity
1	telescopic boom	1
2	pin shaft	1
3	hanger	1
4	chain	1